

Solar Window Film Dark Silver Reflective 20 1520mm

fitting instructions

Please read thoroughly before unpacking or handling film.

very important

Please ensure you are 100% happy with the colour, shade, quantity and style of film before cutting or removing release liner. Once cut or removed from release liner you will not be able to return to us under any circumstances.

Applications are NOT RECOMMENDED in the following situations:

1. When outside temperatures are below freezing or in very bright sunlight.
2. To rough cast glass surfaces.
3. To any dual curved surfaces.

tools required

Washing up liquid, spray bottle, squeegee, craft knife, glass scraper, straight edge, tape measure, soft lint free cloth.

Window film is a very thin sheet of material that requires handling with great care.

Creasing and folding must be avoided. As with aluminium foil, once creased, the film will remain creased and therefore cannot be returned. Applications need to be carried out in a draught and dust free situation.


Preparation and pre-cleaning are vitally important & care must be taken to flush any dirt particles out of the window frame.

Some airborne dust may get under the film, but this is difficult to avoid completely & its presence will not affect the performance of the installation.

1. window preparation


1. Make up the slip solution in the spray bottle (1 tsp washing up liquid, one pint cold water).
2. Thoroughly wash glass with slip solution & squeegee dry.
3. Remove paint, varnish or other foreign matter with a scraper.
4. Spray glass with slip solution & squeegee out, checking that the glass surface is very clean and dust free.

2. film handling



1. Adhesive surface is protected between 'window film' and liner. First establish which side is the thin clear release liner.
2. Window film may be cut to approximate size with a very sharp blade or scissors. It is recommended that the film be cut at least 1/2" longer & wider than the glass. You are now ready to apply the film to the glass.

NOTE: Separate a corner of the 'window film' and liner with 2 small pieces of adhesive tape, one on each side of the product.



Solar Window Film Dark Silver Reflective 20 1520mm

fitting instructions

3. film application



1. Thoroughly wet the glass with the slip solution, this will hold the film in place whilst you remove the clear liner.
 2. Place film on wet glass with liner facing you. From the ready separated corner carefully peel off the liner.
- Spray the adhesive surface generously with the slip solution (you cannot apply too much solution).

3. Carefully reverse film on to the glass so that the adhesive side is now in contact with the glass.



Note: Keep film taut and straight, do not allow film to curl up on itself or to wrinkle. A crease or wrinkle will not flatten out on application.



4. Position the film by gently sliding on wet surface and smoothing out large air bubbles. Ensure all glass area is covered by the film with slight overlap on all sides.

4. squeegee technique

1. Spray the film with the slip solution to give slip for the squeegee.
2. The first stroke should be horizontal across the top of the window.
3. The next stroke should be downwards from one edge with succeeding strokes working down and away from the first strokes.
4. On final squeegee of the top & bottom edges the squeegee may be pushed towards the edges to remove any excess waste.



5. If a particle is trapped behind the film, carefully lift the film from the nearest corner & remove the particle. Before replacing the film, spray sufficient slip solution to thoroughly wet the glass & film. Replace the film & re-squeegee.

5. film trimming

1. Using a straight edge (should have about 1/8" thickness), place it on end at the edge of the window.
2. Trim the film using a razor blade or craft knife so that there is a margin width of the straight edge of about 1/8".
3. Repeat for each edge of the window.



4. After trimming remove excess film.
5. Repeat entire squeegee procedure. A firm pressure is necessary to effect a strong bond.
6. You can then firmly push down all edges with a hard card or credit card wrapped in tissue.

Important note to customer: Sellers and manufacturers only obligation shall be to replace such quantity of the product proved to be defective prior to fitting. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Laws must be adhered to when applying to vehicles.

Prior to all installations you agree that you have checked our film to glass compatibility stated on our website and agree to all of our standard terms and conditions.

DURING DRYING OUT some haziness will be evident & this will disappear & dry out over a 2-4 week period.

CLEANING as you would for normal windows but not until 2 weeks after installation & always with a soft leather or cloth and clean water, never use any abrasive cleaners or cleaners that contain ammonia.